


Data sheet – Spare parts and accessories

Float valves
Types SV 4, SV 5 and SV 6



Description	Pos. #	Qty.	Code no.	
Seal kit				
Sealing ring	1	1	027B2070	
O-ring	2	2		
Washer	3	1		
Washer, nylon	4	1		
Gasket	6	1		
Alu gasket	11	2		
Gasket	12	1		
Alu gasket	13	2		
Alu gasket	14	2		
Service kit				
Valve plate, teflon	9	1		027B2073
Cone incl. tap	10	1		
Locking ring	15	2		
Washer, nylon	16	2		
Strainer				
Strainer	5	1	027B2071	
Orifice assembly				
Gasket	6	1	027B2080	
Orifice dia. 1.0 mm	7	1		
O-ring	8	1		
Valve plate, nylon	9	1		
Orifice assembly				
Gasket	6	1	027B2081	
Orifice dia. 1.5 mm	7	1		
O-ring	8	1		
Valve plate, nylon	9	1		
Orifice assembly				
Gasket	6	1	027B2082	
Orifice dia. 2.0 mm	7	1		
O-ring	8	1		
Valve plate, nylon	9	1		

Description	Pos. #	Qty.	Code no.
Orifice assembly			
Gasket	6	1	027B2083
Orifice dia. 1.0 mm	7	1	
O-ring	8	1	
Valve plate, nylon	9	1	
Orifice assembly			
Gasket	6	1	027B2084
Orifice dia. 1.0 mm	7	1	
O-ring	8	1	
Valve plate, nylon	9	1	
Orifice assembly (default SV 4)			
Gasket	6	1	027B2085
Orifice dia. 3.0 mm	7	1	
O-ring	8	1	
Valve plate, nylon	9	1	
Orifice assembly (default SV 5)			
Gasket	6	1	027B2086
Orifice dia. 3.5 mm	7	1	
O-ring	8	1	
Valve plate, nylon	9	1	
Orifice assembly (default SV 6)			
Gasket	6	1	027B2087
Orifice dia. 4.0 mm	7	1	
O-ring	8	1	
Valve plate, nylon	9	1	
Orifice assembly (default SV 6)			
Alu gasket	11	1	027B2075
Alu gasket	13	1	
Nipple	17	1	
Union	18	1	
Welding nipple	19	1	