





Installation Guide


Accessories HRB, HFE Coupling



		HRB 3 065B2220 ---> 065B2230
		HRB 4 065B2240 ---> 065B2246


		HFE 3, HFE 4 065B5120 ---> 065B5250 065B6132 ---> 065B6250
		HRB 3, HRB 4 ¹⁾ 065B2177 ---> 065B2206
		HRE 3, HRE 4 ¹⁾ 065B5019 ---> 065B5051 065B6019 ---> 065B6051

¹⁾ gen ---> 2008




Installation Guide Accessories HRB, HFE Coupling

2




HRB 3




HRB 4

3





HRB 3



HRB 4

4



Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.