



## Installation guide

# ELIMINATOR® Hermetic filter drier Type DMT

023R9546





023R9546

### Refrigerant R744 (CO<sub>2</sub>)




Maximum working pressure	PS/MWP: 140 bar/2030 psig
Refrigerant temperature	T <sub>min.</sub> : -40 °C / -40 °F
	T <sub>max.</sub> : 100 °C / 212 °F

Flare / flare o-ring / flare NPT  
copper plated solder versions

Connection: All sizes



Keep flames away  
from body



Customer best practice will still be needed:

1. Use wet wrap when installing.
2. Braze the joints.
3. Let them cool down.
4. Clean the welding area after the installation (remove remaining flux with a brush).  
This is an important operation and needs to be done with great care to remove all remaining flux.
5. Paint / Anti-corrosive needs to cover all open steel parts, areas where the black original paint has been burnt due to brazing and at least 3 cm approx of the copper.
6. Paint the joints twice.